

## System Prerequisites


### Recommended configuration

<b>Processor</b>	Pentium® 4 or higher with support of all customary operating systems
<b>Operating system</b>	Microsoft Windows® 2000 / XP / Vista / Win7
<b>Memory</b>	512 MB RAM or higher
<b>Monitor</b>	VGA (1024 x 768)
<b>Drive</b>	CD-ROM
<b>Input device</b>	Mouse or compatible
<b>Interface</b>	USB or COM for data transmission

### Install Software

- Insert the provided CD disk into CD-ROM drive.
- Double-click “XXX\_VX.XX.exe” (X can be 0 to 9 or blank, indicating the software version)
- The pop-up windows will guide you through the program setup process.

### Main Screen




- 1 Main display screen of measurement
- 2 Secondary display screen for measurement
- 3  Blinking indicates meter is connected to the software
- 4 Data Comparison
- 5 Measurement data in graph

### Using Program

Click “USB Connection” or “COM Connection”  and is blinking indicates meter is successfully connected to the PC and meter will automatically start taking measurements. Primary display screen shows measurement, secondary display screen shows all measurement data.

Exit and close the program




No.	Time	Function	Value	Unit	Judge
1	09:46:49	DC	177.1	mV	pass
2	09:46:50	DC	177.0	mV	pass
3	09:46:51	DC	176.9	mV	pass
4	09:46:51	DC	176.9	mV	pass
5	09:46:52	DC	176.9	mV	pass
6	09:46:52	DC	176.9	mV	pass
7	09:46:53	DC	176.9	mV	pass
8	09:46:54	DC	176.9	mV	pass
9	09:46:54	DC	176.8	mV	pass
10	09:46:55	DC	176.8	mV	pass
11	09:46:55	DC	176.7	mV	pass

- 1 Print data
- 2 Save data (\*.txt, \*.xls, \*.xml)
- 3 Open files (\*.txt, \*.xls, \*.xml)
- 4 Deleting current data and create a new data.

**Repeat:** Tick to display every measurement with the interval you set. Un-tick “Repeat”, the secondary display screen will only show measurement result that is different from the last measured value. The curve in curve graph is consistent with that of record sheet, whose X axis only stands for data recording amount.

**Sampling Interval** allows you to set the sampling intervals of measurement ( 1 to 9999 seconds).



- 1 Zoom graphic
- 2 Save graph in current page as \*.bmp
- 3 Deleting current data and create a new data.
- 4 Last page
- 5 Next page
- 6 Current page
- 7 Previous page
- 8 First page
- 9 Set numbers of measurement data on graph display
- 10 Fill or curve